

TOOLS


table saw 1346-636
 cordless drill 1239-121
 3/8" forstner drill bit 1213-895
 sanding block 1061-282

MATERIALS

5/4 x 6 x 8' cedar (1) 2805-615
 3/8" x 4' hardwood dowel (1) 2624-445
 glue - 2020-067
 protective finish of your choice

PARTS

A top - (1) 5/4 x 5 1/4" x 17 3/4"
B legs - (2) 5/4 x 5 x 6 3/4"
C dowels - (8) 3/8" x 2"



MEDITATION BENCH

Cut the two legs and top to size.
 Sand all the edges of the top piece and sand the front and back edges of the legs.

Lay the top piece onto the legs and drill 3/8" through holes into the top piece. Space the holes evenly, approximately 1 1/8" apart.
 Now drill 3/8" x 1" deep holes into the tops of the legs.
 Assemble the bench with glue and dowels.

Sand all surfaces and finish with any Home Hardware product.

